



**FOOTING DETAIL**

1. PLACE SIGN ANCHOR INTO GROUND APPROXIMATELY 2'-6" DEEP. DRILL TWO 7/16" HOLES APPROXIMATELY 1 1/2" FROM THE TOP OF THE ANCHOR POST, PRIOR TO POURING FOOTING.
2. INSERT SIGN POST AND RIVET IN PLACE WITH TWO 3/8" UNIVERSAL HEAD DRIVE RIVETS, ONE PLACED FACING TRAFFIC AND ONE PERPENDICULAR TO TRAFFIC.
3. FOOTING SHALL BE 12" SQUARE OR 12" ROUND.
4. SEE STD. 163 FOR PLACEMENT OF STREET NAME POLE(S).

L:\Public Works - Engineering Standards\INDIO-162 5/19/2016 10:16 AM



*Juan Raya* 05/18/16  
 JUAN RAYA, P.E. DATE  
 CIVIL ENGINEER  
 RCE 68510

REV.	DRAWN BY:	APP'D:	DATE:



**SIGN POST  
 INSTALLATION**

STANDARD PLAN No.: **162**

MAY 2016